



LC2V80FD


(2019)



隆鑫通用动力股份有限公司
LONCIN MOTOR CO., LTD




CYLINDER HEAD L/H




Item No.	Part Number	Description	Q'TY	Remark
1	380140103-0004	Bolt, flange m6×25	4	
2	110690101-0001	Oil filler cap. assy	1	
3	120230165-0001	Cover comp. head	1	
4	120250058-0001	Packing ,head cover	1	
5	380140454-0002	Bolt, flange m10×65	5	
6	380180139-0001	Bolt, stud, ex. 8×42	2	
7	120080786-0001	Head comp., cylinder	1	
8	270960028-0002	Spark plug	1	
9	120150250-0001	Gasket, cylinder head	1	
10	380600122-0001	Pin, dowel	2	
11	160190114-0001	Cowling	1	
12	380140067-0003	Bolt, flange m6×12	2	
13	120550017-0001	Suspend ear	1	
14	380020086-0001	Bolt	1	

CYLINDER HEAD R/H




Item No.	Part Number	Description	Q'TY	Remark
1	380140103-0004	Bolt, flange m6×25	4	
2	110690101-0001	Oil filler cap. Assy	1	
3	120230165-0001	Cover comp. Head	1	
4	120250058-0001	Packing ,head cover	1	
5	380140454-0002	Bolt, flange m10×65	5	
6	270960028-0002	Spark plug	1	
7	120080787-0001	Head comp., cylinder	1	
8	120150250-0001	Gasket, cylinder head	1	
9	380600122-0001	Pin, dowel	2	
10	380180139-0001	Bolt, stud, ex. 8×42	2	
11	160190115-0001	Cowling	1	
12	380140067-0003	Bolt, flange m6×12	2	
13	300710132-0001	Bracket, air cleaner	1	
14	120550017-0001	Suspend ear	1	
15	380140004-0004	Bolt, flange m8×20	1	

CRANKCASE




Item No.	Part Number	Description	Q'TY	Remark
1	380140067-0003	Bolt, flange m6×12	5	
2	160190111-0001	Shroud comp	1	
3	380650337-0001	Oil seal 35×52×7	1	
4	110810365-0001	Crankcase	1	
5	380930114-0001	Clip, oil tube	1	
6	160190112-0001	Shroud comp	1	
7	380140077-0005	Bolt, flange m6×20	1	
8	380140013-0005	Bolt, flange m6×16	3	
9	281890012-0001	Oil protection device	1	
10	110260001-0001	Bolt, drain plug	2	
11	380450591-0001	Washer, plain	2	
12	150350050-0001	Oil fine filter combination	1	
13	150840004-0001	Bolt, oil filter	1	

CRANKCASE




Item No.	Part Number	Description	Q'TY	Remark
14	380840812-0001	"O" ring	1	
15	380780084-0001	Joint	1	
16	380450514-0001	Washer	1	
17	171630035-0001	Shaft, governor arm	1	
18	380450522-0002	Flat washer	2	
19	380650377-0001	OIL SEAL, $\phi 8 \times \phi 14 \times 5$	1	
20	380570024-0003	Split damping ring	1	
21	140250019-0001	Valve, chamber	1	
22	150310020-0001	Strainer	1	
23	110850025-0001	Gasket, breather chamber	1	
24	110840035-0001	Cap, breather chamber	1	
25	380140077-0005	Bolt, flange m6×20	4	
26	380950212-0001	Clip	2	
27	380741182-0001	Tube breather	1	
28	270360140-0001	Starter motor	1	
29	380140190-0003	Bolt, flange m8×90	2	
30	160190113-0001	Shroud comp	1	
31	270850025-0001	Bracket, starting	1	

CRANKCASE COVER




Item No.	Part Number	Description	Q'TY	Remark
1	380140339-0001	Bolt, flange m8×50	10	
2	380650574-0001	Oil seal 40×52×7	1	
3	110820200-0001	Crankcase cover	1	
4	380600123-0001	Pin, dowel 10×12	2	
5	171750043-0001	Governor assy.	1	
6	110830072-0001	Packing, case cover	1	
7	380140067-0003	Bolt, flange m6×12	1	
8	110690116-0001	Oil filler cap. assy	1	
9	283690002-0001	Oil pressure sensor	1	
10	380780084-0001	Joint	1	
11	380450514-0001	Washer	1	
12	150290019-0001	Oil strainer	1	
13	150340012-0001	Cap, oil strainer	1	
14	380140077-0005	Bolt, flange m6×20	5	
15	150010109-0001	Oil pump assy.	1	
16	380640016-0001	Friction ball	1	
17	381150370-0001	Spring, friction	1	
18	380840976-0001	"O" ring	1	
19	380600121-0001	Pin, dowel 8×10	2	
20	150040053-0001	Oil pump cover	1	

CRANKSHAFT & PISTONS




Item No.	Part Number	Description	Q'TY	Remark
1	130070157-0001	Ring set, piston	2	
2	130030226-0001	Piston	2	
3	380560078-0001	Clip, piston pin	4	
4	130060054-0001	Pin, piston	2	
5	130150073-0001	Connecting rod assy	2	
6	130290597-0001	Crankshaft assy	1	

ROCKER/VALVE ASSY




Item No.	Part Number	Description	Q'TY	Remark
1	140390015-0001	Valve locker	8	
2	140380021-0001	Retainer, valve spring	4	
3	140340025-0001	Spring, valve	4	
4	140400012-0001	Seal, valve stem	4	
5	140360010-0001	Seat, valve spring	4	
6	500550037-0001	Valve assy.	2	
7	140020178-0001	Camshaft assy.	1	
8	140450062-0001	Rocker arm assy.	4	
9	140710014-0001	Plate , push rod guide	2	
10	140670037-0001	Push rod	4	
11	140690017-0001	Lifter, valve	4	

FLYWHEEL & BLOWER HOUSING




Item No.	Part Number	Description	Q'TY	Remark
1	270190058-0001	Charging coil assy.	1	120W
2	380190008-0005	Socket head cap screw m6×20	4	
3	270020357-0001	Flywheel comp	1	
4	380451020-0001	Washer	1	
5	380140457-0001	Bolt, flange m12×35	1	
6	160180020-0001	Fan cooling	1	
7	380140004-0004	Bolt, flange m8×20	4	
8	160210141-0001	Fan cover assy.	1	
9	160710007-0001	Plate, fan cover	1	
10	380140013-0005	Bolt, flange m6×16	4	
11	270880244-0001	Rectifier	1	
12	380140103-0004	Bolt, flange m6×25	4	
13	271810062-0001	Start switch assy.	1	
14	271340084-0001	Key, start switch	1	
15	380020086-0001	Bolt	1	
16	270920432-0001	Coil assy., ignition	1	
17	270920433-0001	Coil assy., ignition	1	
18	380140054-0003	Bolt, flange m6×30	4	
19	160010110-0001	Oil cooler assy.	1	
20	380960223-0001	Clamp assy.	4	

FLYWHEEL & BLOWER HOUSING (MANUAL)




Item No.	Part Number	Description	Q'TY	Remark
1	270190060-0001	Charging coil assy.	1	
2	380190008-0005	Socket head cap screw m6×20	4	
3	270020357-0001	Flywheel comp	1	
4	380451020-0001	Washer	1	
5	380140457-0001	Bolt, flange m12×35	1	
6	160180020-0001	Fan cooling	1	
7	380140004-0004	Bolt, flange m8×20	4	
8	160850006-0001	Impeller casing	1	
9	160710007-0001	Plate, fan cover	1	
10	380140013-0005	Bolt, flange m6×16	4	
11	270880261-0001	Rectifier	1	
12	380140103-0004	Bolt, flange m6×25	4	
13	271810062-0001	Start switch assy.	1	
14	271340084-0001	Key, start switch	1	
15	380020086-0001	Bolt	1	
16	270920432-0001	Coil assy., ignition	1	
17	270920433-0001	Coil assy., ignition	1	
18	380140054-0003	Bolt, flange m6×30	4	
19	160010110-0001	Oil cooler assy.	1	
20	380960223-0001	Clamp assy.	4	
21	193660003-0001	Start disc seat	1	
22	193590007-0001	Pulley ,starter	1	
23	380140766-0001	Bolt, flange m12×20	1	
24	193500176-0001	Starter assy.	1	
25	380140067-0003	Bolt, flange m6×12	5	

CARBURETTOR




Item No.	Part Number	Description	Q'TY	Remark
1	380140375-0001	Bolt, flange m6×85	4	
2	180280103-0001	Base, air cleaner	1	
3	170430192-0001	Packing .,carburettor	1	
4	170022095-0001	Carburettor assy.	1	
5	170430191-0001	Packing .,carburettor	1	
6	380140054-0003	Bolt, flange m6×30	2	
7	180420661-0001	Connector	1	
8	170430190-0001	Packing .,carburettor	2	
9	170440101-0001	Spacer, carburettor	1	
10	170430210-0001	Packing .,carburettor	2	
11	380140051-0005	Bolt, flange m8×35	4	
12	180420749-0001	Intake manifold	1	
13	380950188-0001	Clamp, pipe	1	

CARBURETTOR




Item No.	Part Number	Description	Q'TY	Remark
14	380750942-0001	FUEL PIPE	1	
15	170460031-0001	FUEL PUMP ASSY	1	
16	174680002-0001	COVER,FUEL PUMP	1	
17	380140103-0004	BOLT, FLANGE M6×25	2	
18	380770292-0001	PROTECTING TUBE	1	
19	380750381-0001	FUEL PIPE	2	
20	380960120-0004	CLIP ASSY.	6	
21	380741320-0001	TUBE, BREATHER	1	
22	170010045-0001	FUEL FILTERS	1	

CONTROL (CABLE)




Item No.	Part Number	Description	Q'TY	Remark
1	380140067-0003	Bolt, flange m6×12	6	
2	171730073-0001	Fuel control assy.	1	
3	171210615-0001	Accelerator, rope	1	
4	171600127-0001	Governor spring	1	
5	175030002-0001	Clamp, throttle return	1	
6	171620051-0001	Governor bracket	1	
7	380370066-0002	Nut, flange	1	
8	380250003-0002	Bolt, quadrate head	1	
9	171610039-0001	Spring, throttle return	1	
10	171590042-0001	Rod, governor	1	
11	171680183-0001	Control assy.	1	
12	173710005-0001	Sleeve, control	1	
13	171650045-0001	Choke linkage	1	
14	172920012-0001	Choke lever	1	

CONTROL (FIXED)




Item No.	Part Number	Description	Q'TY	Remark
1	380140067-0003	Bolt, flange m6×12	4	
2	171730073-0001	Fuel control assy.	1	
3	380140013-0005	Bolt, flange m6×16	1	
4	171600126-0001	Governor spring	1	
5	175030002-0001	Clamp, throttle return	1	
6	171620051-0001	Governor bracket	1	
7	380370066-0002	Nut, flange	1	
8	380250003-0002	Bolt, quadrate head	1	
9	171610039-0001	Spring, throttle return	1	
10	171590042-0001	Rod, governor	1	
11	171650045-0001	Choke linkage	1	
12	172920010-0001	Choke lever	1	

AIR FILTER (A)




Item No.	Part Number	Description	Q'TY	Remark
1	180020901-0001	Air cleaner	1	
2	180070265-0001	Cover, air cleaner	1	
3	180100113-0001	Element, air cleaner	1	
4	180330062-0001	Support, air cleaner	1	
5	380140067-0003	Bolt, flange m6×12	2	
6	380140375-0001	Bolt, flange m6×85	1	

AIR FILTER (B)



Item No.	Part Number	Description	Q'TY	Remark
1	180021047-0001	Air cleaner	1	
2	180180169-0001	Connecting tube, air cleaner	1	
3	662710002-0001	Inlet cover, air cleaner	1	
4	180280071-0001	Base, air cleaner	1	
5	180100126-0001	Element, air cleaner	1	
6	180100082-0001	Element, air cleaner	1	
7	380840861-0001	Seal, air cleaner seat	1	
8	180070195-0001	Cover, air cleaner	1	
9	180290046-0001	Bracket, air cleaner	1	
10	381150648-0001	Spring	1	
11	380823445-0001	Bush	1	
12	380140336-0001	Bolt, flange m8×60	1	
13	180220033-0002	Supporting plate, air cleaner	1	
14	380140067-0003	Bolt, flange m6×12	2	
15	380140375-0001	Bolt, flange m6×85	1	
16	380140040-0005	Bolt, flange m8×16	2	

EXHAUST



Item No.	Part Number	Description	Q'TY	Remark
1	180650130-0001	Gasket, muffler	2	
2	180572403-0001	Muffler	1	
3	180990138-0001	Bracket, muffler	1	
4	380340005-0009	Nut, m8	4	
5	380140004-0004	Bolt, flange, m8×20	2	
6	380460001-0006	Washer	2	